

The Sure-Fit™ Process

An interactive approach to making custom milled abutments



Full contour wax-up with margin line set in black



Final custom abutment wax-up (Soft tissue is used in production)



Final custom abutment



Sure-Fit™ Jig for easy placement



NobelProcera P3™ zirconia coping

1

Wax-up to full contour.

2

Receive Doctor feedback on full contour & cutback wax to shape of custom abutment.

3

Approve abutment design and proceed with production.

4

Doctor places custom abutment with the "Sure-Fit™ Jig" for easy placement.

5

Doctor places the final NobelProcera P3 Zirconia restoration.

The custom milled abutment and the NobelProcera P3 Zirconia coping are fabricated simultaneously to provide a Sure-Fit™ restoration!

ProCereX now has the ability to fabricate custom milled abutments on the following platforms...



Call 602.298.1388
www.ProCereX.com

PRO CEREX
DENTAL LABORATORY